



INSTRUKCJA OBSŁUGI


Pistolet do pianki profesjonalny

Typ: T00220, Model: CY-099




Wyprodukowano dla
F.H. GEKO
Kietlin, ul. Spacerowa 3
97-500 Radomsko
www.geko.pl

Przed pierwszym użyciem prosimy dokładnie zapoznać się z niniejszą instrukcją obsługi. Zapoznanie się z wszelkimi instrukcjami, niezbędnymi do bezpiecznego użytkowania i obsługi oraz zrozumienie wszelkiego ryzyka, jakie może wystąpić podczas eksploatacji urządzenia należy do obowiązków ich użytkownika.



JĘZYK POLSKI



Przed przystąpieniem do eksploatacji niniejszego urządzenia przeczytaj całą instrukcję i zachowaj ją.

ZASTOSOWANIE

Pistolet do pianki montażowej jest przeznaczony do nakładania pianki jednoskładnikowej dostępnej w pojemnikach ciśnieniowych. Pistolet ułatwia wykonywanie takich prac jak: uszczelnianie, montaż okien i drzwi, wypełnianie szczelin w izolacji, uszczelnianie i izolacja ścianek działowych oraz ocieplanie ścian i dachów

ZALECENIA BEZPIECZEŃSTWA

Szczegółowe instrukcje dotyczące bezpieczeństwa stosowania pianki montażowej są zawarte przez producentów na opakowaniach pianki i należy się do nich bezwzględnie stosować.

Nigdy nie kierować wylotu pistoletu w kierunku ludzi

Na stanowisku pracy powinna być zapewniona skuteczna wentylacja.

Pistolet należy używać z daleka od źródeł ciepła i ognia. Nigdy nie kierować strumienia pianki montażowej, lub środka czyszczącego na źródło ciepła bądź ognia, może to spowodować pożar.

Przestrzegać ogólnych zasad bezpieczeństwa przy wykonywaniu prac montażowych i stosować odpowiednio dobrane środki ochrony osobistej takie jak okulary, maski i rękawice.

Nie dopuszczać dzieci w pobliże zmontowanego układu.

INSTRUKCJA UŻYTKOWANIA

Przed rozpoczęciem pracy skontrolować stan pistoletu.

Silnie wstrząsnąć pojemnikiem z pianką, przez około 30 sekund.

Zaleca się nasmarować gniazdo mocowania zasobnika oraz głowice z zaworem iglicowym wazeliną lub olejem silnikowym.

Wkręcić pojemnik do gniazda pistoletu do wyczuwalnego oporu.

Nacisnąć dźwignię spustową i napęlnić pistolet pianką. Ilość piany reguluje się pokrętką regulacji piany.

Pistolet jest gotowy do użytku.

Zwolnienie nacisku dźwigni spustowej powoduje zatrzymanie wypływu pianki.

Zalecane jest nie wykręcanie pojemnika z pianką z pistoletu.

Nie wolno dopuszczać do zaschnięcia pianki wewnątrz pistoletu. Zaschniętą piankę można usunąć tylko mechanicznie.

W celu ponownego użycia silnie wstrząsnąć pistoletem z zamocowanym pojemnikiem, przez około 15 sekund.

Po opróżnieniu zasobnika należy go odkręcić z gniazda pistoletu, oczyścić pistolet z ewentualnych zabrudzeń, a następnie wkręcić nowy zasobnik.

Po zakończonej pracy (jeżeli nie musimy wymieniać pojemnika) odkręcić pojemnik od pistoletu aby nie dopuścić do zaschnięcia pianki a następnie starannie wyczyścić.

Wkręcić zasobnik ze środkiem czyszczącym do gniazda mocowania zasobnika z pianą i wytryskiwać do momentu aż pistolet będzie całkowicie czysty. Do czyszczenia nie należy stosować wody, używamy jedynie środków zalecanych przez producenta. Gniazdo mocowania zasobnika z pianą, dysza i głowica muszą być zawsze czyste.

Tvardy



ENGLISH

Please read these instructions carefully before using this foam gun and retain for the future reference.

1. INTENDED USE OF THE PRODUCT

This gun has been designed for use with polyurethane foams and should not be used for any other application. This gun is used for various repair and building works, such as door and window replacement, joining various frame constructions, silencing and sealing gaps in walls.

2. BEFORE YOU USE

Always read the foam manufactures instructions when handling and using their product in conjunction with this gun.

Never point the gun at humans or animals and do not discharge unless in use

Only use the gun in adequately ventilated rooms with the correct respiratory protection equipment

Many foam products contain highly inflammable chemicals, do not use in the proximity of any open flames, cigarettes or any other potential cause of combustion

Always wear approved safety clothing and personal protection equipment: gloves, goggles for eye protection, a mask with the appropriate activated carbon filters when working with the foam gun.

Keep the gun out of the reach of children.

3. INSTRUCTIONS FOR PROPER AND SAFE USE OF THE TOOL.

Always inspect the gun before use to ensure it is not damaged. If in doubt do not use the gun and contact your dealer

Shake can vigorously for 30 seconds prior to installing can on to foam gun.

Make sure the gun basket is perfectly clean and apply some Vaseline or light grease to the inside of the gun basket area. This helps prevent foam from curing to the basket and gluing the can on to the gun.

Screw the cartridge onto the guns adaptor until it is tight. Do not over tighten as this may cause damage to the threads

Pull the trigger to start the foam flow, this may be regulated by adjusting the rear knob until the desired foam bead is achieved

Gun is now ready to use.

Release the trigger and tighten the regulating knob to lock the needle in the closed position, to prevent accidental discharge when the gun is not in use.

Always store the gun with the can attached in the normal use position

Replace empty cartridges as soon as possible to avoid hardening of the foam in the gun

To re-use, simply shake the foam can vigorously for 30 seconds.

When the cartridge is emptied unscrew it out of the foam gun socket. Clean possible dirt with cleanser and screw new cartridge in.

If the gun is not to be reloaded it must be cleaned as soon as possible after the cartridge has been removed to avoid hardening of the foam inside the gun.

Once the foam has become hard solvents will not necessarily dissolve all residues

Always ensure all foam is released from the gun before cleaning

Never use water to clean the gun

Only clean the gun with recommended cleaning solvents, any other solvents may damage the gun

Leave the solvent in the gun for 2 minutes. Release the solvent by pressing the trigger and repeat this process until the solvent runs clear and shows no trace of foam. Unscrew the regulating knob and remove the needle, clean the needle with non abrasive cleaning solvent. Note - hardened foam will damage the needle. Remove the front nozzle with a set screw wrench and check the nozzle for hardened foam. Clean as necessary with an appropriate solvent