



Marka:	TRESNAR
Model:	4538

Item No.	Part Name
1	Screw
2	Flat wahser
3	Outer flange
4	Saw blade
5	Inner flange
6	Screw
7	Screw
8	Flange for guard
9	Spanner
10	Guard
11	Spindle
12	Hemi-cycle key
13	Bearing
14	Front cover
15	Location steel sleeve
16	Gear
17	Retain ring
18	Oily bearing
19	Small piece of iron
20	Screw
21	Rating plate
22	Screw
23	Flat washer
24	Nut
25	Self-locked spring
26	Self-locked piece
27	Screw
28	Base
29	Circlip
30	Angle locked wrench

Item No.	Part Name
31	Long nut
32	Rivet
33	Flat washer
34	Angle support
35	Screw
36	Angle active rack
37	Screw
38	Depth locked wrench cap
39	Depth locked wrench
40	Special nut
41	Depth active rack
42	Rivet
43	Screw
44	Screw
45	Fixed guard
46	Spring
47	Nameplate
48	Laser head
49	Screw
50	Screw
51	Side cover
52	Laser seat
53	Laser switch
54	Laser
55	Screw
56	Bearing
57	Rotor
58	Brush cap
59	Carbon brush
60	Brush holder
61	Bearing
62	Bearing sleeve
63	Nut

Item No.	Part Name
64	Baffle
65	Screw
66	Wire damper
67	Stator
68	Connector
69	Housing
70	Rating plate
71	Screw
72	Screw
73	Rear housing
74	Screw
75	Auxiliary handle cover
76	Auxiliary handle
77	Screw
78	Flat washer
79	Spring washer
80	Screw
81	Screw
82	Left handle
83	Capacitor
84	Switch
85	Transformer
86	Right handle
87	Cord clamp
88	Cable sleeve
89	Cable
90	Guide
91	Hex spanner

Marka:	TRESNAR
Model:	4538